

This page has the codes needed to connect and disconnect KDC300 as a keyboard using Bluetooth. This page is divided into four quadrants and is designed to be folded once horizontally and once vertically to isolate the codes for scanning. The codes are located in the middle of each quadrant.

Step 1. Scan the code in this quadrant to set the KDC 300 to Bluetooth-HID keyboard mode.



Step 2. Scan the code in this quadrant to start pairing so that your phone or PC can find the KDC300.



The KDC300 may take a moment to process this code.

Step 3: Begin Bluetooth discovery on the phone or PC and select the KDC300 device.

Step 4. If a confirmation to pair with the KDC300 appears, confirm that you want to connect. You are now connected! The LED display on the KDC300 will read "HID connected" You can now scan codes!

To disconnect the KDC 300, click the button on the side of the KDC 300 or scan the code in this quadrant to disconnect KDC300 when done using the KDC300.

To reconnect click the "up" menu key on the side of the KDC300 or scan the code in this quadrant to reconnect the KDC300.

